

INDEX

In order of connector No.

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
A	A-01	Side turn signal lamp (RH)	B-135,139	B-6,8
	A-02	Side turn signal lamp (LH)	B-134,138	B-6,8
	A-03	Wheel speed sensor (Front:LH)	B-203,211,217,225,233,243	B-6,8
	A-04X	Spare connector (for front fog lamp relay)	B-73,258	B-6,8
	A-05X	Horn relay	B-73,146	B-6,8
	A-06X	Condenser fan relay (LO)	B-73,177,183	B-6,8
	A-07X	Condenser fan relay (HI)	B-73,177,183	B-6,8
	A-08X	No connection	B-73	B-6,8
	A-09X	Radiator fan relay	B-73,102,176,182	B-6,8
	A-10X	Front-ECU	B-73,75,103,104,106,107,110,111,114,115,124,127,130,131,132,133,136,140,187,191, 258	B-6,8
	A-11X	Front-ECU	B-73,104,106,107,111,115,124,127,131,133, 136,140,186,187,190,191	B-6,8
	A-12	Front wiring harness (LH) and control wiring harness combination <ABS>	B-198,206	B-6,8
	A-13	Front wiring harness (LH) and control wiring harness combination <LHD>	B-86,90,102,176,178,186,252	B-6
	A-16	Headlamp (HI:LH)	B-103,106	B-6,8
	A-21	Fan controller	B-102,176,182	B-7,8
	A-23	Horn (HI)	B-146	B-7,8
	A-25	Horn (LO)	B-146	B-7,9
	A-28	Headlamp (HI:RH)	B-103,106	B-7,9
	A-31	Spare connector (for front fog lamp)	B-258	B-7,9
	A-34	No connection	-	B-9
	A-36	Dual pressure switch	B-178,184	B-7,9
	A-37	Wheel speed sensor (Front:RH)	B-203,211,217,225,233,243	B-7,9
	A-39	Front combination lamp (LH)	B-103,106,110,114,130,132,134,138	B-7,9
	A-40	Front combination lamp (RH)	B-103,106,111,114,130,132,135,139	B-7,9
	A-43	Front wiring harness (LH) and control wiring harness combination <LHD>	B-82,84,177,178,203,217,233	B-7
	A-44	Intercooler water spray motor	B-256	B-7,9

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
A	A-45	Condenser fan motor	B-177,183	B-7,9
	A-46	Condenser fan motor	B-177,183	B-7,9
	A-47	A/C compressor	B-178,184	B-7,9
	A-48	Power steering oil pressure switch	B-90,98	B-7,9
B	B-01	Windshield wiper motor	B-186,190	B-10,14
	B-02	Throttle position sensor	B-89,97,215,223,231,241	B-10,14
	B-03	Vehicle speed sensor	B-92,100,150,154,197	B-10,14
	B-04	Brake fluid level switch	B-157	B-10,14
	B-05X	Engine speed detection connector	B-73,82,83,90,98	B-10,14
	B-06X	No connection	B-73	B-10,14
	B-07X	No connection	B-73	B-10,14
	B-08X	No connection	B-73	B-10,14
	B-09X	Ignition coil relay <RHD> or no connection <LHD>	B-73,83	B-10,14
	B-10X	No connection	B-73	B-10,14
	B-11X	Engine control relay	B-73,86,94,252,254	B-10,14
	B-12X	A/C compressor relay	B-73,178,184	B-10,14
	B-14	Control wiring harness and battery wiring harness combination	B-79,84,91,99,157	B-10,14
	B-18	Starter	B-79	B-11,15
	B-19	Starter	B-79	B-11,15
	B-20	Oil pressure switch	B-157	B-11,15
	B-21	Alternator	B-84	B-11,15
	B-22	Alternator	B-84	B-11,15
	B-23	Purge control solenoid valve	B-91,99	B-11,15
	B-24	Injector 4	B-89,97	B-11,15
	B-25	Injector 3	B-89,97	B-11,15
	B-26	Injector 2	B-89,97	B-11,15
	B-27	Injector 1	B-89,97	B-11,15
	B-31	Air flow sensor	B-90,98	B-11,15
	B-34	Oxygen sensor	B-88,96	B-11,15
	B-36	Waste gate solenoid valve	B-91,99	B-11,15
B-37	Fuel pressure solenoid valve	B-90,98	B-11,15	

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
B	B-108	Back-up lamp switch	B-142,143	B-12,16
	B-110	Engine coolant temperature gauge unit	B-148,152	B-12,16
	B-112	EGR solenoid valve	B-91,99	B-12,16
	B-114	Ignition coil 1	B-82,83	B-12,16
	B-115	Idle speed control servo	B-88,96	B-12,16
	B-116	Camshaft position sensor	B-88,96	B-12,16
	B-118	Engine coolant temperature sensor	B-89,97	B-12,16
	B-119	Ignition coil 2	B-82,83	B-12,16
	B-121	Crank angle sensor	B-88,96	B-13,16
	B-122	Detonation sensor	B-89,97	B-13,17
	B-123	ABS-ECU	B-198,200,201,202,203,204,205,206,208,209,210,211,229,232,233,239,242,243	B-13,17
	B-138	Resistor	B-89,97	B-13,17
	B-139	Electric pump relay <ACD>	B-216,224,234,244	B-13,17
	B-140	Fuel pump relay 3	B-93,101	B-13,17
	B-141	Fuel pump resistor	B-93,101	B-13,17
B-142	Secondary air control solenoid valve	B-91,99	B-13,17	
C	C-01	Combination meter	B-84,87,95,103,106,118,122,126,129,135,139,148,149,152,153,156,157,198,206,214,222,230,240,248,250,256,258	B-18,24
	C-02	Combination meter	B-110,115,118,122,126,129,135,139,148,149,152,153,156,157,198,206,248,250,256,258	B-18,24
	C-03	Hazard warning switch	B-136,140	B-18,24
	C-04	Clock	B-194	B-18,24
	C-05	J/C (1)	B-56,62,93,101,104,107,111,112,115,116,118,122,124,125,127,128,131,133,136,137,140,141,148,152,153,156,158,164,170,172,175,181,185,187,191,194,195,196,197,212,214,220,222,228,230,238,240,257	B-18,24
	C-08	J/C (3)	B-58,64,95,104,105,107,108,112,113,116,117,119,123,124,125,126,127,128,129,131,133,136,137,140,141,149,153,159,164,165,171,172,173,175,180,181,185,187,188,189,191,193,194,195,202,210,214,218,222,226,227,230,236,240,246,247,253,255,257,258	B-18,24

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C	C-10	Outside/Inside air selection damper control motor and potentiometer	B-175,181	B-18,24
	C-14	Blower motor	B-174,180	B-18,24
	C-16	Resistor	B-174,180	B-18,24
	C-21	SRS-ECU	B-248,249,250,251	B-18,24
	C-22	Diagnosis connector	B-92,100,105,108,113,117,119,123,125,128,137,141,150,154,158,164,170,172,188,189,204,205,219,227,237,247,248,250,252,254	B-18,24
	C-23	Diagnosis connector	B-92,100	B-18,24
	C-24	Instrument panel wiring harness and front door wiring harness (LH) combination	B-162,163,165,170,172,173,192,193,196	B-18,24
	C-26	J/C (4)	B-59,65,92,100,105,113,119,137,157,158,170,188,194,197,201,204,205,209,213,219,221,227,232,237,242,247,250,252,254,258	B-19,25
	C-28	J/C (5) <RHD>	B-66,100,108,117,123,141,164,172,173,189,205,227,247,254	B-25
	C-29	J/C (5) <LHD>	B-60,84,87,104,112,125,137,149,150,157,187,194,197,198,214,230,248,256	B-19
	C-32	A/C-ECU or heater control unit	B-175,181,185	B-19,25
	C-34	No connection <RHD>	-	B-25
	C-35	Instrument panel wiring harness and instrument panel wiring harness combination <RHD>	B-76,78,100,108,117,123,128,141,154,164,165,172,180,185,189,205,227,247,250,254	B-25
	C-36	Headlamp leveling switch	B-131,133	B-19,25
	C-41	SRS-ECU	B-249,251	B-19,25
	C-42	Instrument panel wiring harness and control wiring harness combination <ACD> <LHD>	B-216,234	B-19
	C-43	4WD-ECU <ACD>	B-201,209,212,213,214,215,216,218,219,220,221,222,223,224,226,227,228,230,231,232,234,236,237,238,240,241,242,244,246,247	B-19,25
	C-44	4WD-ECU <ACD>	B-201,209,212,213,216,217,219,220,221,224,225,227,228,229,232,234,235,237,238,239,242,244,245,247	B-19,25
	C-45	Instrument panel wiring harness and floor wiring harness (LH) combination <LHD>	B-216,234	B-19

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C	C-46	Control wiring harness and floor wiring harness (LH) combination <ACD> <RHD>	B-224,244	B-25
	C-101	Spare connector (for front fog lamp switch)	B-258	B-20,26
	C-102	J/C (2)	B-57,63,87,92,104,105,107,111,113,115,119,124,126,127,131,136,140,143,154,158,163,169,170,175,181,187,188,191,192,202,204,210,218,219,226,236,237,246,248,252,256,258	B-20,26
	C-103	Stop lamp switch	B-144,145,198,206,212,220,228,238	B-20,26
	C-104	Spare connector (for radio)	B-196,197	B-20,26
	C-107	Instrument panel wiring harness and A/C wiring harness combination	B-175,181	B-20,26
	C-108	J/C (6)	B-61,67,82,83,86,88,90,92,94,96,98,100,102,149,153,176,182,198,204,205,206,212,215,219,223,228,231,237,241,252,253,254,255	B-20,26
	C-109	Air bag module (squib) <Passenger's side>	B-249,251	B-20,26
	C-110	Instrument panel wiring harness and front door wiring harness (RH) combination	B-159,168,169,170,171,172,192,193,196	B-20,26
	C-111	Front wiring harness (RH) and instrument panel wiring harness combination	B-103,106,135,139,157,178,184,203,211,217,225,233,243	B-20,26
	C-112	Instrument panel wiring harness and floor wiring harness (RH) combination	B-111,120,134,142,143,144,145,159,160,165,166,171,186,190,197,249,251	B-20,26
	C-115	Engine-ECU	B-87,88,89,90,91,92,93,95,96,97,98,99,100,101,215,223,231,241,257	B-20,26
	C-118	Engine-ECU	B-82,83,88,90,91,92,93,96,98,99,100,101,149,153,252,254,256	B-20,26
	C-122	Engine-ECU	B-84,86,87,90,91,93,94,95,98,99,101,177,178,183,184,252,254,256,257	B-20,26
	C-126	Engine-ECU	B-82,83,86,88,89,90,91,93,94,96,97,98,99,101,102,178,184	B-20,26
	C-128	Instrument panel wiring harness and control wiring harness combination	B-153,181,184,198,200,202,203,205,206,208,209,211,213,214,216,217,218,229,230,233,234,235,236,239,242,243	B-21,26
	C-129	Instrument panel wiring harness and control wiring harness combination	B-79,80,83,87,89,93,95,97,101,142,143,149,186,190,212,228,253	B-21,26

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C	C-130	Instrument panel wiring harness and control wiring harness combination	B-84,87,92,95,100,142,143,148,150,152,154,157,175,178,198,200,201,204,205,206,212,213,216,219,228,229,232,235,237,252,254,255,256,257	B-21,27
	C-131	Blower switch	B-174,180	B-21,27
	C-132	Front wiring harness (LH) and instrument panel wiring harness combination	B-74,78,92,100,105,108,113,117,119,123,125,128,137,141,150,154,158,159,164,165,170,172,174,180,185,188,189,204,205,219,227,237,247,248,250,252,254	B-21,27
	C-133	Instrument panel wiring harness and floor wiring harness (LH) combination	B-114,121,126,138,143,144,145,159,161,165,167,173,249,251	B-21,27
	C-134	Instrument panel wiring harness and floor wiring harness (LH) combination	B-216,224,234,235,244,245	B-21,27
	C-135	Front wiring harness (LH) and instrument panel wiring harness combination	B-76,82,87,93,95,101,103,104,106,107,110,111,114,115,118,122,124,127,128,130,131,132,133,134,135,136,138,139,140,144,145,146,148,149,152,153,156,158,164,170,172,175,177,181,183,185,186,187,190,191,194,195,196,197,198,206,212,214,220,222,228,230,238,240,256,257,258	B-21,27
	C-136	Front wiring harness (LH) and control wiring harness combination <RHD>	B-83,84,94,98,102,182,183,184,190,211,225,243,254	B-27
	C-137	Fog lamp switch	B-124,127	B-21,27
	C-138	Remote controlled mirror switch	B-192,193	B-21,27
	C-141	Roof antenna	B-196	B-21,27
	C-142	ACD mode changeover switch	B-214,222,230,240	B-21,27
	C-146	Instrument panel wiring harness and floor wiring harness (RH) combination	B-93,101,129,148,152,156,203,211,217,225,233,243	B-21,27
	C-147	Instrument panel wiring harness and control wiring harness combination <RHD>	B-209,210,215,223,224,225,231,241,242,244	B-27
	C-201	Ignition switch	B-76	B-22,28
	C-202	Key reminder switch	B-253,255	B-22,28
	C-203	Column switch	B-104,107,112,116,125,128,137,141,187,191	B-22,28
	C-204	Clock spring <SRS>	B-248,250	B-22,28
	C-205	Clock spring <SRS>	B-146	B-22,28
	C-206	Horn switch <SRS>	B-146	B-22,28

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C	C-207	Air bag module (squib) <Driver's side>	B-248,250	B-22,28
	C-208	Instrument panel wiring harness and J/B combination	B-54,55,126,129,256	B-22,28
	C-209	Instrument panel wiring harness and J/B combination	B-54,55,87,95,104,105,107,108,110,111,112,115,116,118,122,125,128,134,136,137,138,139,140,141,142,143,149,153,158,164,170,172,174,180,186,187,188,189,190,191,189,198,202,206,210,218,222,226,236,240,246,256	B-22,28
	C-210	Instrument panel wiring harness and J/B combination	B-54,55,76,77,78,82,83,84,87,95,104,107,111,112,115,116,118,122,125,128,136,137,140,141,142,143,149,153,157,158,159,164,165,170,172,174,180,185,186,187,190,191,192,193,195,198,200,202,206,208,210,212,213,214,218,220,221,222,226,228,229,230,236,238,239,240,246,248,250,256	B-22,28
	C-211	Instrument panel wiring harness and J/B combination	B-54,55,78,92,100,105,108,113,117,119,123,125,128,137,141,150,154,158,164,170,172,174,180,185,188,189,204,205,219,227,237,247,248,250,252,254	B-22,28
	C-213	Instrument panel wiring harness and J/B combination	B-54,55,78,82,83,84,87,92,95,100,104,105,107,108,110,112,113,115,116,117,119,120,121,123,125,126,128,129,135,136,137,139,140,141,149,150,153,154,157,158,164,170,171,172,173,174,180,185,187,188,189,191,192,193,195,198,200,204,205,206,208,212,213,214,219,220,221,222,227,228,229,230,237,238,239,240,247,248,250,252,254,256	B-22,28
	C-214	Defogger relay	B-54,55,78,185	B-23,29
	C-215	Blower relay	B-54,55,174,180	B-23,29
	C-216	Floor wiring harness (LH) and J/B combination <LHD>	B-54,55,105,110,112,119,120,134,158,171,185	B-23
	C-217	Floor wiring harness (RH) and J/B combination <RHD>	B-54,55,108,115,116,121,123,138,164,173,185	B-29
	C-218	Roof wiring harness (RH) and J/B combination	B-54,55,118,119,122,123	B-23,29
	C-219	Rear fog lamp relay	B-54,55,126,129	B-23,29
	C-220	No connection	B-54,55	B-23,29
	C-221	Fuel pump relay 2	B-54,55,87,95	B-23,29
	C-222	Intercooler water spray relay	B-54,55,256	B-23,29

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C	C-223	Fuel pump relay 1	B-54,55,87,95	B-23,29
	C-224	Power window relay	B-54,55,158,159,165	B-23,29
	C-225	No connection	B-54,55,78	B-23,29
	C-226	ETACS-ECU	B-54,55,105,108,112,113,116,117,118,119,120,121,122,123,125,126,128,129,134,136,137,138,140,141,158,164,165,170,171,172,173,188,189	B-23,29
	C-227	ETACS-ECU	B-125,128,170,172	B-23,29
	C-228	ETACS-ECU	B-105,108,112,113,116,117,118,119,122,123,125,126,128,129,136,137,140,141,158,159,164,165,170,171,172,173,188,189,258	B-23,29
	C-230	Steering wheel sensor	B-202,210,218,226,236,246	B-23,29
	D	D-01	Door switch (Front:RH)	B-108,116,120,121,164
D-02		Floor wiring harness (RH) and rear door wiring harness (RH) combination	B-160,166,171,173	B-30,32
D-03		Room lamp	B-118,122	B-30,32
D-04		Wheel speed sensor (Rear:RH) <ABS,ACD>	B-203,211,217,225,233,243	B-30,32
D-05		Rear room lamp	B-118,122	B-30,32
D-06		Door switch (Rear:RH)	B-120,121	B-30,32
D-08		Door switch (Rear:LH)	B-120,121	B-30,32
D-09		Fuel pump and fuel gauge unit (Main)	B-93,101,148,152,156	B-30,32
D-10		Wheel speed sensor (Rear:LH) <ABS,ACD>	B-203,211,217,225,233,243	B-30,32
D-12		Floor wiring harness (LH) and rear door wiring harness (LH) combination	B-161,167,171,173	B-30,32
D-13		Door switch (Front:LH)	B-105,112,120,121,158	B-30,32
D-15		Instrument panel wiring harness and console wiring harness combination	B-195	B-31,32
D-18		Cigarette lighter	B-195	B-31,33
D-19		Cigarette lighter	B-195	B-31,33
D-20		Ashtray illumination lamp	B-195	B-31,33
D-21		Cigarette lighter illumination lamp	B-195	B-31,33
D-22		Oxygen sensor (Rear)	B-88,96	B-31,33
D-23		Parking brake switch	B-157,201,209,213,221,232,242	B-31,33
D-26	Seat belt pretensioner (RH)	B-249,251	B-31,33	

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page	
D	D-27	Fuel gauge unit (Sub)	B-148,152,156	B-31,33	
	D-28	Seat belt pretensioner (LH)	B-249,251	B-31,33	
	D-29	Floor wiring harness (RH) and fuel wiring harness combination	B-93,101	B-31,33	
	D-30	Floor wiring harness (RH) and fuel wiring harness combination	B-93,101,148,152,156,203,211,217,225,233,243	B-31,33	
	D-32	G sensor (Longitudinal)	B-200,208,213,221,229,239	B-31,33	
	D-33	G sensor (Lateral)	B-200,208,213,221,229,239	B-31,33	
	D-34	Intercooler water spray switch	B-257	B-31,33	
E	E-02	Remote controlled mirror (LH)	B-192,193	B-34,36	
	E-04	Spare connector <for front door speaker (LH)>	B-196	B-34,36	
	E-05	Power window motor (Front:LH)	B-162,165	B-34,36	
	E-07	Power window main switch	B-162,163,168,169	B-34,36	
	E-08	Door lock actuator (Front:LH)	B-170,173	B-34,36	
	E-10	Power window motor (Rear:LH)	B-161,167	B-34,36	
	E-11	Power window sub switch (Rear:LH)	B-161,167	B-34,36	
	E-12	Door lock actuator (Rear:LH)	B-171,173	B-34,36	
	E-13	Remote controlled mirror (RH)	B-192,193	B-34,36	
	E-16	Door lock key cylinder switch (RH)	B-170	B-35	
	E-17	Door lock key cylinder switch (LH)	B-172	B-37	
	E-18	Door lock actuator (Front:RH)	B-171,172	B-35,37	
	E-19	Power window sub switch (Passenger's side)	B-159,165	B-35,37	
	E-20	Power window motor (Front:RH)	B-159,168	B-35,37	
	E-21	Spare connector <for front door speaker (RH)>	B-196	B-35,37	
	E-23	Door lock actuator (Rear:RH)	B-171,173	B-35,37	
	E-24	Power window sub switch (Rear:RH)	B-160,166	B-35,37	
	E-25	Power window motor (Rear:RH)	B-160,166	B-35,37	
	F	F-01	Spare connector <for rear speaker (LH)>	B-197	B-38,39
		F-04	Luggage compartment lamp	B-119,123	B-38,39
		F-05	High mounted stop lamp	B-144,145	B-38,39
		F-06	Defogger (-)	B-185	B-38,39

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
F	F-08	Spare connector <for rear speaker (RH)>	B-197	B-38,39
	F-09	Rear combination lamp (RH)	B-111,115,129,134,138,142,144,145	B-38,39
	F-10	Trunk lid latch switch	B-119,123	B-38,39
	F-12	Licence plate lamp (RH)	B-110,114	B-38,39
	F-13	Licence plate lamp (LH)	B-110,114	B-38,39
	F-14	Floor wiring harness (LH) and bumper wiring harness combination	B-110,114	B-38,39
	F-16	Rear combination lamp (LH)	B-110,114,126,134,138,143,144,145	B-38,39
	F-19	Defogger (+)	B-185	B-38,39
	F-21	Windshield washer motor	B-186,190	B-38,39
	F-23	Electric pump <ACD>	B-216,224,234,244	B-38,39
	F-24	Floor wiring harness (LH) and 4WD wiring harness combination <ACD>	B-216,224,234,235,244,245	B-38,39
	F-25	Direction valve (LH) <ACD>	B-235,245	B-38,39
	F-26	Direction valve (RH) <ACD>	B-235,245	B-38,39
	F-27	Proportioning valve (for ACD control)	B-216,224,235,245	B-38,39
	F-28	Proportioning valve (for AYC control)	B-235,245	B-38,39
	F-29	Pressure sensor <ACD>	B-216,224,234,244	B-38,39

INDEX

In order of parts name

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
	4WD-ECU <ACD>	C-43	B-201,209,212,213,214,215,216,218,219,220,221,222,223,224,226,227,228,230,231,232,234,236,237,238,240,241,242,244,246,247	B-19,25
	4WD-ECU <ACD>	C-44	B-201,209,212,213,216,217,219,220,221,224,225,227,228,229,232,234,235,237,238,239,242,244,245,247	B-19,25
A	A/C compressor	A-47	B-178,184	B-7,9
	A/C compressor relay	B-12X	B-73,178,184	B-10,14
	A/C-ECU or heater control unit	C-32	B-175,181,185	B-19,25
	ABS-ECU	B-123	B-198,200,201,202,203,204,205,206,208,209,210,211,229,232,233,239,242,243	B-13,17
	ACD mode changeover switch	C-142	B-214,222,230,240	B-21,27
	Air bag module (squib) <Driver's side>	C-207	B-248,250	B-22,28
	Air bag module (squib) <Passenger's side>	C-109	B-249,251	B-20,26
	Air flow sensor	B-31	B-90,98	B-11,15
	Alternator	B-21	B-84	B-11,15
	Alternator	B-22	B-84	B-11,15
	Ashtray illumination lamp	D-20	B-195	B-31,33
B	Back-up lamp switch	B-108	B-142,143	B-12,16
	Blower motor	C-14	B-174,180	B-18,24
	Blower relay	C-215	B-54,55,174,180	B-23,29
	Blower switch	C-131	B-174,180	B-21,27
	Brake fluid level switch	B-04	B-157	B-10,14
C	Camshaft position sensor	B-116	B-88,96	B-12,16
	Cigarette lighter	D-18	B-195	B-31,33
	Cigarette lighter	D-19	B-195	B-31,33
	Cigarette lighter illumination lamp	D-21	B-195	B-31,33
	Clock	C-04	B-194	B-18,24
	Clock spring <SRS>	C-204	B-248,250	B-22,28
	Clock spring <SRS>	C-205	B-146	B-22,28

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
C	Column switch	C-203	B-104,107,112,116,125,128,137,141,187,191	B-22,28
	Combination meter	C-01	B-84,87,95,103,106,118,122,126,129,135,139,148,149,152,153,156,157,198,206,214,222,230,240,248,250,256,258	B-18,24
	Combination meter	C-02	B-110,115,118,122,126,129,135,139,148,149,152,153,156,157,198,206,248,250,256,258	B-18,24
	Condenser fan motor	A-45	B-177,183	B-7,9
	Condenser fan motor	A-46	B-177,183	B-7,9
	Condenser fan relay (HI)	A-07X	B-73,177,183	B-6,8
	Condenser fan relay (LO)	A-06X	B-73,177,183	B-6,8
	Control wiring harness and battery wiring harness combination	B-14	B-79,84,91,99,157	B-10,14
	Control wiring harness and floor wiring harness (LH) combination <ACD> <RHD>	C-46	B-224,244	B-25
	Crank angle sensor	B-121	B-88,96	B-13,16
D	Defogger (-)	F-06	B-185	B-38,39
	Defogger (+)	F-19	B-185	B-38,39
	Defogger relay	C-214	B-54,55,78,185	B-23,29
	Detonation sensor	B-122	B-89,97	B-13,17
	Diagnosis connector	C-22	B-92,100,105,108,113,117,119,123,125,128,137,141,150,154,158,164,170,172,188,189,204,205,219,227,237,247,248,250,252,254	B-18,24
	Diagnosis connector	C-23	B-92,100	B-18,24
	Direction valve (LH) <ACD>	F-25	B-235,245	B-38,39
	Direction valve (RH) <ACD>	F-26	B-235,245	B-38,39
	Door lock actuator (Front:LH)	E-08	B-170,173	B-34,36
	Door lock actuator (Front:RH)	E-18	B-171,172	B-35,37
	Door lock actuator (Rear:LH)	E-12	B-171,173	B-34,36
	Door lock actuator (Rear:RH)	E-23	B-171,173	B-35,37
	Door lock key cylinder switch (LH)	E-17	B-172	B-37
	Door lock key cylinder switch (RH)	E-16	B-170	B-35
	Door switch (Front:LH)	D-13	B-105,112,120,121,158	B-30,32
	Door switch (Front:RH)	D-01	B-108,116,120,121,164	B-30,32

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
D	Door switch (Rear:LH)	D-08	B-120,121	B-30,32
	Door switch (Rear:RH)	D-06	B-120,121	B-30,32
	Dual pressure switch	A-36	B-178,184	B-7,9
E	EGR solenoid valve	B-112	B-91,99	B-12,16
	Electric pump <ACD>	F-23	B-216,224,234,244	B-38,39
	Electric pump relay <ACD>	B-139	B-216,224,234,244	B-13,17
	Engine control relay	B-11X	B-73,86,94,252,254	B-10,14
	Engine coolant temperature gauge unit	B-110	B-148,152	B-12,16
	Engine coolant temperature sensor	B-118	B-89,97	B-12,16
	Engine speed detection connector	B-05X	B-73,82,83,90,98	B-10,14
	Engine-ECU	C-115	B-87,88,89,90,91,92,93,95,96,97,98,99,100,101,215,223,231,241,257	B-20,26
	Engine-ECU	C-118	B-82,83,88,90,91,92,93,96,98,99,100,101,149,153,252,254,256	B-20,26
	Engine-ECU	C-122	B-84,86,87,90,91,93,94,95,98,99,101,177,178,183,184,252,254,256,257	B-20,26
	Engine-ECU	C-126	B-82,83,86,88,89,90,91,93,94,96,97,98,99,101,102,178,184	B-20,26
	ETACS-ECU	C-226	B-54,55,105,108,112,113,116,117,118,119,120,121,122,123,125,126,128,129,134,136,137,138,140,141,158,164,165,170,171,172,173,188,189	B-23,29
	ETACS-ECU	C-227	B-125,128,170,172	B-23,29
ETACS-ECU	C-228	B-105,108,112,113,116,117,118,119,122,123,125,126,128,129,136,137,140,141,158,159,164,165,170,171,172,173,188,189,258	B-23,29	
F	Fan controller	A-21	B-102,176,182	B-7,8
	Floor wiring harness (LH) and 4WD wiring harness combination <ACD>	F-24	B-216,224,234,235,244,245	B-38,39
	Floor wiring harness (LH) and bumper wiring harness combination	F-14	B-110,114	B-38,39
	Floor wiring harness (LH) and J/B combination <LHD>	C-216	B-54,55,105,110,112,119,120,134,158,171,185	B-23
	Floor wiring harness (LH) and rear door wiring harness (LH) combination	D-12	B-161,167,171,173	B-30,32
	Floor wiring harness (RH) and fuel wiring harness combination	D-29	B-93,101	B-31,33
	Floor wiring harness (RH) and fuel wiring harness combination	D-30	B-93,101,148,152,156,203,211,217,225,233,243	B-31,33

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
F	Floor wiring harness (RH) and J/B combination <RHD>	C-217	B-54,55,108,115,116,121,123,138,164,173,185	B-29
	Floor wiring harness (RH) and rear door wiring harness (RH) combination	D-02	B-160,166,171,173	B-30,32
	Fog lamp switch	C-137	B-124,127	B-21,27
	Front combination lamp (LH)	A-39	B-103,106,110,114,130,132,134,138	B-7,9
	Front combination lamp (RH)	A-40	B-103,106,111,114,130,132,135,139	B-7,9
	Front wiring harness (LH) and control wiring harness combination <ABS>	A-12	B-198,206	B-6,8
	Front wiring harness (LH) and control wiring harness combination <LHD>	A-13	B-86,90,102,176,178,186,252	B-6
	Front wiring harness (LH) and control wiring harness combination <LHD>	A-43	B-82,84,177,178,203,217,233	B-7
	Front wiring harness (LH) and control wiring harness combination <RHD>	C-136	B-83,84,94,98,102,182,183,184,190,211,225,243,254	B-27
	Front wiring harness (LH) and instrument panel wiring harness combination	C-132	B-74,78,92,100,105,108,113,117,119,123,125,128,137,141,150,154,158,159,164,165,170,172,174,180,185,188,189,204,205,219,227,237,247,248,250,252,254	B-21,27
	Front wiring harness (LH) and instrument panel wiring harness combination	C-135	B-76,82,87,93,95,101,103,104,106,107,110,111,114,115,118,122,124,127,128,130,131,132,133,134,135,136,138,139,140,144,145,146,148,149,152,153,156,158,164,170,172,175,177,181,183,185,186,187,190,191,194,195,196,197,198,206,212,214,220,222,228,230,238,240,256,257,258	B-21,27
	Front wiring harness (RH) and instrument panel wiring harness combination	C-111	B-103,106,135,139,157,178,184,203,211,217,225,233,243	B-20,26
	Front-ECU	A-10X	B-73,75,103,104,106,107,110,111,114,115,124,127,130,131,132,133,136,140,187,191,258	B-6,8
	Front-ECU	A-11X	B-73,104,106,107,111,115,124,127,131,133,136,140,186,187,190,191	B-6,8
	Fuel gauge unit (Sub)	D-27	B-148,152,156	B-31,33
	Fuel pressure solenoid valve	B-37	B-90,98	B-11,15
	Fuel pump and fuel gauge unit (Main)	D-09	B-93,101,148,152,156	B-30,32
	Fuel pump relay 1	C-223	B-54,55,87,95	B-23,29
	Fuel pump relay 2	C-221	B-54,55,87,95	B-23,29
	Fuel pump relay 3	B-140	B-93,101	B-13,17
	Fuel pump resistor	B-141	B-93,101	B-13,17

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
G	G sensor (Lateral)	D-33	B-200,208,213,221,229,239	B-31,33
	G sensor (Longitudinal)	D-32	B-200,208,213,221,229,239	B-31,33
H	Hazard warning switch	C-03	B-136,140	B-18,24
	Headlamp (HI:LH)	A-16	B-103,106	B-6,8
	Headlamp (HI:RH)	A-28	B-103,106	B-7,9
	Headlamp leveling switch	C-36	B-131,133	B-19,25
	High mounted stop lamp	F-05	B-144,145	B-38,39
	Horn (HI)	A-23	B-146	B-7,8
	Horn (LO)	A-25	B-146	B-7,9
	Horn relay	A-05X	B-73,146	B-6,8
	Horn switch <SRS>	C-206	B-146	B-22,28
I	Idle speed control servo	B-115	B-88,96	B-12,16
	Ignition coil 1	B-114	B-82,83	B-12,16
	Ignition coil 2	B-119	B-82,83	B-12,16
	Ignition coil relay <RHD> or no connection <LHD>	B-09X	B-73,83	B-10,14
	Ignition switch	C-201	B-76	B-22,28
	Injector 1	B-27	B-89,97	B-11,15
	Injector 2	B-26	B-89,97	B-11,15
	Injector 3	B-25	B-89,97	B-11,15
	Injector 4	B-24	B-89,97	B-11,15
	Instrument panel wiring harness and A/C wiring harness combination	C-107	B-175,181	B-20,26
	Instrument panel wiring harness and console wiring harness combination	D-15	B-195	B-31,32
	Instrument panel wiring harness and control wiring harness combination	C-128	B-153,181,184,198,200,202,203,205,206,208,209,211,213,214,216,217,218,229,230,233,234,235,236,239,242,243	B-21,26
	Instrument panel wiring harness and control wiring harness combination	C-129	B-79,80,83,87,89,93,95,97,101,142,143,149,186,190,212,228,253	B-21,26
Instrument panel wiring harness and control wiring harness combination	C-130	B-84,87,92,95,100,142,143,148,150,152,154,157,175,178,198,200,201,204,205,206,212,213,216,219,228,229,232,235,237,252,254,255,256,257	B-21,27	

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
I	Instrument panel wiring harness and control wiring harness combination <ACD> <LHD>	C-42	B-216,234	B-19
	Instrument panel wiring harness and control wiring harness combination <RHD>	C-147	B-209,210,215,223,224,225,231,241,242,244	B-27
	Instrument panel wiring harness and floor wiring harness (LH) combination	C-133	B-114,121,126,138,143,144,145,159,161,165,167,173,249,251	B-21,27
	Instrument panel wiring harness and floor wiring harness (LH) combination	C-134	B-216,224,234,235,244,245	B-21,27
	Instrument panel wiring harness and floor wiring harness (LH) combination <LHD>	C-45	B-216,234	B-19
	Instrument panel wiring harness and floor wiring harness (RH) combination	C-112	B-111,120,134,142,143,144,145,159,160,165,166,171,186,190,197,249,251	B-20,26
	Instrument panel wiring harness and floor wiring harness (RH) combination	C-146	B-93,101,129,148,152,156,203,211,217,225,233,243	B-21,27
	Instrument panel wiring harness and front door wiring harness (LH) combination	C-24	B-162,163,165,170,172,173,192,193,196	B-18,24
	Instrument panel wiring harness and front door wiring harness (RH) combination	C-110	B-159,168,169,170,171,172,192,193,196	B-20,26
	Instrument panel wiring harness and instrument panel wiring harness combination <RHD>	C-35	B-76,78,100,108,117,123,128,141,154,164,165,172,180,185,189,205,227,247,250,254	B-25
	Instrument panel wiring harness and J/B combination	C-208	B-54,55,126,129,256	B-22,28
	Instrument panel wiring harness and J/B combination	C-209	B-54,55,87,95,104,105,107,108,110,111,112,115,116,118,122,125,128,134,136,137,138,139,140,141,142,143,149,153,158,164,170,172,174,180,186,187,188,189,190,191,189,198,202,206,210,218,222,226,236,240,246,256	B-22,28
	Instrument panel wiring harness and J/B combination	C-210	B-54,55,76,77,78,82,83,84,87,95,104,107,111,112,115,116,118,122,125,128,136,137,140,141,142,143,149,153,157,158,159,164,165,170,172,174,180,185,186,187,190,191,192,193,195,198,200,202,206,208,210,212,213,214,218,220,221,222,226,228,229,230,236,238,239,240,246,248,250,256	B-22,28

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
I	Instrument panel wiring harness and J/B combination	C-211	B-54,55,78,92,100,105,108,113,117,119,123,125,128,137,141,150,154,158,164,170,172,174,180,185,188,189,204,205,219,227,237,247,248,250,252,254	B-22,28
	Instrument panel wiring harness and J/B combination	C-213	B-54,55,78,82,83,84,87,92,95,100,104,105,107,108,110,112,113,115,116,117,119,120,121,123,125,126,128,129,135,136,137,139,140,141,149,150,153,154,157,158,164,170,171,172,173,174,180,185,187,188,189,191,192,193,195,198,200,204,205,206,208,212,213,214,219,220,221,222,227,228,229,230,237,238,239,240,247,248,250,252,254,256	B-22,28
	Intercooler water spray motor	A-44	B-256	B-7,9
	Intercooler water spray relay	C-222	B-54,55,256	B-23,29
	Intercooler water spray switch	D-34	B-257	B-31,33
J	J/C (1)	C-05	B-56,62,93,101,104,107,111,112,115,116,118,122,124,125,127,128,131,133,136,137,140,141,148,152,153,156,158,164,170,172,175,181,185,187,191,194,195,196,197,212,214,220,222,228,230,238,240,257	B-18,24
	J/C (2)	C-102	B-57,63,87,92,104,105,107,111,113,115,119,124,126,127,131,136,140,143,154,158,163,169,170,175,181,187,188,191,192,202,204,210,218,219,226,236,237,246,248,252,256,258	B-20,26
	J/C (3)	C-08	B-58,64,95,104,105,107,108,112,113,116,117,119,123,124,125,126,127,128,129,131,133,136,137,140,141,149,153,159,164,165,171,172,173,175,180,181,185,187,188,189,191,193,194,195,202,210,214,218,222,226,227,230,236,240,246,247,253,255,257,258	B-18,24
	J/C (4)	C-26	B-59,65,92,100,105,113,119,137,157,158,170,188,194,197,201,204,205,209,213,219,221,227,232,237,242,247,250,252,254,258	B-19,25
	J/C (5) <LHD>	C-29	B-60,84,87,104,112,125,137,149,150,157,187,194,197,198,214,230,248,256	B-19
	J/C (5) <RHD>	C-28	B-66,100,108,117,123,141,164,172,173,189,205,227,247,254	B-25
	J/C (6)	C-108	B-61,67,82,83,86,88,90,92,94,96,98,100,102,149,153,176,182,198,204,205,206,212,215,219,223,228,231,237,241,252,253,254,255	B-20,26

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
K	Key reminder switch	C-202	B-253,255	B-22,28
L	Licence plate lamp (LH)	F-13	B-110,114	B-38,39
	Licence plate lamp (RH)	F-12	B-110,114	B-38,39
	Luggage compartment lamp	F-04	B-119,123	B-38,39
N	No connection	A-08X	B-73	B-6,8
	No connection	A-34	-	B-9
	No connection	B-07X	B-73	B-10,14
	No connection	B-08X	B-73	B-10,14
	No connection	B-10X	B-73	B-10,14
	No connection	C-220	B-54,55	B-23,29
	No connection	B-06X	B-73	B-10,14
	No connection	C-225	B-54,55,78	B-23,29
	No connection <RHD>	C-34	-	B-25
O	Oil pressure switch	B-20	B-157	B-11,15
	Outside/Inside air selection damper control motor and potentiometer	C-10	B-175,181	B-18,24
	Oxygen sensor	B-34	B-88,96	B-11,15
	Oxygen sensor (Rear)	D-22	B-88,96	B-31,33
P	Parking brake switch	D-23	B-157,201,209,213,221,232,242	B-31,33
	Power steering oil pressure switch	A-48	B-90,98	B-7,9
	Power window main switch	E-07	B-162,163,168,169	B-34,36
	Power window motor (Front:LH)	E-05	B-162,165	B-34,36
	Power window motor (Front:RH)	E-20	B-159,168	B-35,37
	Power window motor (Rear:LH)	E-10	B-161,167	B-34,36
	Power window motor (Rear:RH)	E-25	B-160,166	B-35,37
	Power window relay	C-224	B-54,55,158,159,165	B-23,29
	Power window sub switch (Passenger's side)	E-19	B-159,165	B-35,37
	Power window sub switch (Rear:LH)	E-11	B-161,167	B-34,36
	Power window sub switch (Rear:RH)	E-24	B-160,166	B-35,37
	Pressure sensor <ACD>	F-29	B-216,224,234,244	B-38,39
	Proportioning valve (for ACD control)	F-27	B-216,224,235,245	B-38,39
Proportioning valve (for AYC control)	F-28	B-235,245	B-38,39	

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
P	Purge control solenoid valve	B-23	B-91,99	B-11,15
R	Radiator fan relay	A-09X	B-73,102,176,182	B-6,8
	Rear combination lamp (LH)	F-16	B-110,114,126,134,138,143,144,145	B-38,39
	Rear combination lamp (RH)	F-09	B-111,115,129,134,138,142,144,145	B-38,39
	Rear fog lamp relay	C-219	B-54,55,126,129	B-23,29
	Rear room lamp	D-05	B-118,122	B-30,32
	Remote controlled mirror (LH)	E-02	B-192,193	B-34,36
	Remote controlled mirror (RH)	E-13	B-192,193	B-34,36
	Remote controlled mirror switch	C-138	B-192,193	B-21,27
	Resistor	B-138	B-89,97	B-13,17
	Resistor	C-16	B-174,180	B-18,24
	Roof antenna	C-141	B-196	B-21,27
	Roof wiring harness (RH) and J/B combination	C-218	B-54,55,118,119,122,123	B-23,29
	Room lamp	D-03	B-118,122	B-30,32
S	Seat belt pretensioner (LH)	D-28	B-249,251	B-31,33
	Seat belt pretensioner (RH)	D-26	B-249,251	B-31,33
	Secondary air control solenoid valve	B-142	B-91,99	B-13,17
	Side turn signal lamp (LH)	A-02	B-134,138	B-6,8
	Side turn signal lamp (RH)	A-01	B-135,139	B-6,8
	Spare connector (for front fog lamp relay)	A-04X	B-73,258	B-6,8
	Spare connector (for front fog lamp switch)	C-101	B-258	B-20,26
	Spare connector (for front fog lamp)	A-31	B-258	B-7,9
	Spare connector (for radio)	C-104	B-196,197	B-20,26
	Spare connector <for front door speaker (LH)>	E-04	B-196	B-34,36
	Spare connector <for front door speaker (RH)>	E-21	B-196	B-35,37
	Spare connector <for rear speaker (LH)>	F-01	B-197	B-38,39
	Spare connector <for rear speaker (RH)>	F-08	B-197	B-38,39
	SRS-ECU	C-21	B-248,249,250,251	B-18,24

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
S	SRS-ECU	C-41	B-249,251	B-19,25
	Starter	B-18	B-79	B-11,15
	Starter	B-19	B-79	B-11,15
	Steering wheel sensor	C-230	B-202,210,218,226,236,246	B-23,29
	Stop lamp switch	C-103	B-144,145,198,206,212,220,228,238	B-20,26
T	Throttle position sensor	B-02	B-89,97,215,223,231,241	B-10,14
	Trunk lid latch switch	F-10	B-119,123	B-38,39
V	Vehicle speed sensor	B-03	B-92,100,150,154,197	B-10,14
W	Waste gate solenoid valve	B-36	B-91,99	B-11,15
	Wheel speed sensor (Front:LH)	A-03	B-203,211,217,225,233,243	B-6,8
	Wheel speed sensor (Front:RH)	A-37	B-203,211,217,225,233,243	B-7,9
	Wheel speed sensor (Rear:LH) <ABS,ACD>	D-10	B-203,211,217,225,233,243	B-30,32
	Wheel speed sensor (Rear:RH) <ABS,ACD>	D-04	B-203,211,217,225,233,243	B-30,32
	Windshield washer motor	F-21	B-186,190	B-38,39
	Windshield wiper motor	B-01	B-186,190	B-10,14