

COLT

TECHNICAL INFORMATION

FOREWORD

MANUAL

This manual has been prepared as an introduction to the specifications, features, construction, functions, etc. of the newly developed COLT.

Please read this manual carefully so that it will be of assistance for your service activities. Please note the following service manuals are also available and should be used in conjunction with this manual.

WORKSHOP MANUAL CHASSIS GROUP BODY REPAIR MANUAL

PARTS CATALOGUE

All information, illustrations and product descriptions contained in this manual are current as of the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

MAIN INDEX

General	00
Engine	11
Engine Lubrication	12
Fuel	13
Engine Cooling	14
Intake and Exhaust	15
Engine Electrical	16
Engine and Emission Control	17
Clutch	21
Manual Transmission	22
Continuously Variable Transmission (CVT)	23
Front Axle	26
Rear Axle	27
Wheel and Tyre	31
Power Plant Mount	32
Front Suspension	33
Rear Suspension	34
Service Brakes	35
Parking Brakes	36
Steering	37
Body	42
Exterior	51
Interior and Supplemental Restraint System (SRS)	52
Chassis Electrical	54
Heater, Air Conditioner and Ventilation	55

 $\mathbf{0}$

