



WORKSHOP MANUAL

SUPPLEMENT

LANCER EVOLUTION-VIII



LANCER

EVOLUTION VIII

FOREWORD

This manual contains details of the main changes to the '03 model Lancer Evolution VIII. Since only differences to the Lancer Evolution VII have been included, please use this manual in conjunction with the relevant pages in the material previously published.

We recommend that work is carried out with careful reference to this manual, to ensure that servicing is done correctly and quickly, so that vehicle performance is maintained.

This manual is based on the current model (January 2003). Please bear in mind that as a result of subsequent changes to vehicle specifications, some information may not correspond to more recently published details.

All the units shown in this manual follow the internationally recognised SI unit system. Please note that the practice of using the old units together with SI units has been dropped. (Please note, however, that figures and units specified on various forms may still use the old units)

Any opinions, requests, or questions concerning this manual, should be written on the 'Servicing Comment Form' at the end, and sent to us by fax.

January 2003



MITSUBISHI MOTOR CORPORATION

CONTENTS

General

00

Engine

11

Fuel

13

Engine Cooling

14

Intake and Exhaust

15

Engine Electrical

16

Engine and Emission Control

17

Manual Transmission

22

Front Axle

26

Rear Axle

27

Engine and Transmission Mounting

32

Body

42

Exterior

51

Interior and SRS Airbag

52

Chassis Electrical

54

Related materials

Title	No.	Issue date
New model manuals		
• Mirage, Lancer	1036F30	10/1995
• Mirage, Lancer	1036F31	1/1996
• Mirage, Lancer	1036F32	8/1996
• Mirage, Lancer	1036F33	7/1997
• Lancer	1036F34	1/1998
• Mirage, Lancer	1036F35	10/1998
• Lancer	1036F36	1/1999
• Lancer	1036F37	12/1999
• Lancer Sedia	1036K30	5/2000
• Lancer Sedia	1036K31	7/2000
• Lancer Evolution VII	1036K32	1/2001
• Lancer Sedia	1036K33	5/2001
• Lancer Sedia	1036K34	5/2001
• Lancer Evolution VII	1036K35	1/2002
• Lancer Sedia	1036K36	5/2002
• Lancer Evolution VII	1036K37	1/2003
Workshop Manuals		
• Lancer Sedia	1036k00	5/2000
• Lancer Sedia (supplement)	1036K01	7/2000
• Lancer Evolution VII (supplement)	1036K02	1/2001
• Lancer Sedia (supplement)	1036K03	5/2001
• Lancer Sedia (supplement)	1036K04	10/2001
• Lancer Evolution VII (supplement)	1036K05	1/2002
• Lancer Sedia (supplement)	1036K06	5/2002
Body edition Workshop Manuals		
• Mirage, Lancer (supplement)	1036F32	8/1996
• Lancer Sedia	1036K50	5/2000
• Lancer Sedia (supplement)	1036K51	7/2000
• Lancer Evolution VII (supplement)	1036K52	5/2001
• Lancer Sedia (supplement)	1036K53	10/2001
Electrical Wiring Diagrams Workshop Manuals		
• Lancer Evolution VIII	1036K77	1/2003
Engine Workshop Manuals		
• 4G6 engine	1039G46	1/2001
• 4G6 engine (supplement)	1039G63	1/2003
Transmission Workshop Manual		
• W5M51 manual transmission	1039M17	1/2001
• W5M51 manual transmission (supplement)	1039M22	1/2003
• W6MAA manual transmission	1039M23	1/2003

WARNING REGARDING SERVICING OF VEHICLES FITTED WITH SRS AIR BAGS · SEAT BELTS WITH PRE-TENSIONERS

Warning

1. Improper servicing or maintenance of any SRS air bag or pretensioner fitted seatbelt component, or related parts, could cause major injury as a result of the unintentional setting-off (incorrect deployment) of the SRS air bag or pretensioner fitted seatbelt, or non-operation.
2. When they could be subject to the effects of heat during the painting process, please remove the SRS-ECU, driver side air bag module, passenger side air bag module, pretensioner fitted seatbelt, and clock spring, as follows:
 - 93°C and above: driver side air bag module, passenger side air bag module, clock spring
 - 90°C and above: pretensioner fitted seat belts
3. Service or maintenance of any SRS air bag or pretensioner fitted seatbelt components or related parts must be performed by an authorised MITSUBISHI dealer.
4. This manual must be consulted (with special reference to Chapter 52B SRS Air Bag) before any servicing or maintenance is carried out on SRS air bag or pretensioner fitted seatbelt components or related parts.

Note

Sections titles with an asterisk (*) indicate areas where special attention must be paid to SRS airbags and pretensioner fitted seatbelts.

SECTION 13

FUEL

CONTENTS

Multipoint Injection (MPI).....13A

Fuel supply.....13B

SECTION 52**INTERIOR & SRS****CONTENTS**

Interior.....52A

Supplemental Restraint System (SRS).....52B

SECTION 54

CHASSIS ELECTRICAL

CONTENTS

Chassis Electrical.....54A

Smart Wiring System (SWS).....54B